
DAP

MANUAL



ENGLISH

PA-530DAB V1

Ordercode: D6156

Table of contents

Warning **2**
Safety Instructions 2
Operating Determinations 4
Connection with the mains 4
Return Procedure 4
Claims 4

Description of the device **5**
Frontside 7
Backside 9
Tuner 11
Audio Player 12

Installation **13**

Set Up and Operation **13**
Connecting Inputs 13
Operating the FM Tuner 13
Searching for Radio Stations 13
Tuning 13
Storing a Radio Station in Memory 14
Operating the DAB+ Tuner 14
Refreshing the DAB+ Radio Station List 14
Storing a Radio Station in Memory 14
Operating the Audio Player 15
Selecting Tracks 15
Auto Start/Pausing Playback 15
Stopping Playback 15
Repeat Function 15
Selecting Folders and Tracks 16
Connecting Outputs 17
Low Impedance Outputs 17
High Impedance Outputs 17

Connection Cables **18**

Maintenance **19**
Replacing the Fuse 19

Troubleshooting **19**

Product Specifications **20**

Dimensions **22**

Warning


For your own safety, please read this user manual carefully before your initial start-up!

Unpacking Instructions

Immediately upon receiving this product, carefully unpack the carton and check the contents to ensure that all parts are present, and have been received in good condition. Notify the dealer immediately and retain packing material for inspection if any parts appear damaged from shipping or the carton itself shows signs of mishandling. Save the carton and all packing materials. In the event that a device must be returned to the factory, it is important that the device is returned in the original factory box and packing.

Your shipment includes:

- DAP Audio PA-530DAB
- FM Antenna
- IEC power cable – 1,5 m
- User manual



CAUTION!
Keep this device away from rain and moisture!
Unplug mains lead before opening the housing!

Safety Instructions

Every person involved with the installation, operation and maintenance of this system has to:

- be qualified
- follow the instructions of this manual

CAUTION! Be careful with your operations.
With a dangerous voltage you can suffer
a dangerous electric shock when touching the wires!

Before you initial start-up, please make sure that there is no damage caused by transportation. Should there be any, consult your dealer and do not use the system.

To maintain perfect condition and to ensure a safe operation, it is absolutely necessary for the user to follow the safety instructions and warning notes written in this manual.

Please consider that damages caused by manual modifications to the system are not subject to warranty.

This system contains no user-serviceable parts. Refer servicing to qualified technicians only.

IMPORTANT:

The manufacturer will not accept liability for any resulting damages caused by the non-observance of this manual or any unauthorized modification to the system.

- Never let the power cord come into contact with other cables! Handle the power cord and all connections with the mains with particular caution!
- Never remove warning or informative labels from the unit.
- Never use anything to cover the ground contact.
- Never leave any cables lying around.
- Do not insert objects into air vents.
- Do not connect this system to a dimmerpack.
- Do not switch the system on and off in short intervals, as this would reduce the system's life.
- Do not open the device and do not modify the device.
- Do not drive the inputs with a signal level bigger, than required to drive the equipment to full output.
- Do not plug mics into the console (or stagebox) while phantom power is on. Also mute the monitor / Pa system when turning phantom power on or off. Allow the system to adjust for a couple of seconds, before setting the input gains.
- Only use system indoors, avoid contact with water or other liquids.
- Avoid flames and do not put close to flammable liquids or gases.
- Always disconnect power from the mains, when system is not used. Only handle the power cord by the plug. Never pull out the plug by tugging the power cord.
- Always operate the unit with the AC ground wire connected to the electrical system ground.
- Make sure you do not use the wrong kind of cables or defective cables.
- Make sure that the signals into the mixer are balanced, otherwise hum could be created.
- Make sure you use DI boxes to balance unbalanced signals; All incoming signals should be clear.
- Make sure that the available voltage is not higher than stated on the rear panel.
- Make sure that the power cord is never crimped or damaged. Check the system and the power cord from time to time.
- Please turn off the power switch, when changing the power cord or signal cable, or select the input mode switch.
- Extreme frequency boosts in connection with a high input signal level may lead to overdriving your equipment. Should this occur, it is necessary to reduce the input signal level by using the INPUT control.
- To emphasize a frequency range, you do not necessarily have to move its respective control upward; try lowering surrounding frequency ranges instead. This way, you avoid causing the next piece of equipment in your sound path to overdrive. You also preserve valuable dynamic reserve ("headroom").
- Avoid ground loops! Always be sure to connect the power amps and the mixing console to the same electrical circuit to ensure the same phase!
- If system is dropped or struck, disconnect mains power supply immediately. Have a qualified engineer inspect for safety before operating.
- If the system has been exposed to drastic temperature fluctuation (e.g. after transportation), do not switch it on immediately. The arising condensation water might damage your system. Leave the system switched off until it has reached room temperature.
- If your Dap Audio device fails to work properly, discontinue use immediately. Pack the unit securely (preferably in the original packing material), and return it to your Dap Audio dealer for service.
- Repairs, servicing and electric connection must be carried out by a qualified technician.
- For replacement use fuses of same type and rating only.
- WARRANTY: Till one year after date of purchase.

Operating Determinations

This system is not designed for permanent operation. Consistent operation breaks will ensure that the system will serve you for a long time without defects.

If this system is operated in any other way, than the one described in this manual, the product may suffer damages and the warranty becomes void.
Any other operation may lead to dangers like short-circuit, burns, electric shock, etc.

You endanger your own safety and the safety of others!

Improper installation can cause serious damage to people and property !

Connection with the mains

Connect the device to the mains with the power-plug.
Always pay attention, that the right color cable is connected to the right place.

International	EU Cable	UK Cable	US Cable	Pin
L	BROWN	RED	YELLOW/COPPER	PHASE
N	BLUE	BLACK	SILVER	NEUTRAL
⏚	YELLOW/GREEN	GREEN	GREEN	PROTECTIVE GROUND

Make sure that the device is always connected properly to the earth!

Improper installation can cause serious damage to people and property!

⚠ Return Procedure ⚠

Returned merchandise must be sent prepaid and in the original packing, call tags will not be issued. Package must be clearly labeled with a Return Authorization Number (RMA number). Products returned without an RMA number will be refused. Highlite will not accept the returned goods or any responsibility. Call Highlite 0031-455667723 or mail aftersales@highlite.nl and request an RMA prior to shipping the fixture. Be prepared to provide the model number, serial number and a brief description of the cause for the return. Be sure to properly pack fixture, any shipping damage resulting from inadequate packaging is the customer's responsibility. Highlite reserves the right to use its own discretion to repair or replace product(s). As a suggestion, proper UPS packing or double-boxing is always a safe method to use.

Note: If you are given an RMA number, please include the following information on a piece of paper inside the box:

01) Your name
02) Your address
03) Your phone number
04) A brief description of the symptoms

Claims

The client has the obligation to check the delivered goods immediately upon delivery for any short-comings and/or visible defects, or perform this check after our announcement that the goods are at their disposal. Damage incurred in shipping is the responsibility of the shipper; therefore the damage must be reported to the carrier upon receipt of merchandise.
It is the customer's responsibility to notify and submit claims with the shipper in the event that a fixture is damaged due to shipping. Transportation damage has to be reported to us within one day after receipt of the delivery.
Any return shipment has to be made post-paid at all times. Return shipments must be accompanied with a letter defining the reason for return shipment. Non-prepaid return shipments will be refused, unless otherwise agreed in writing.
Complaints against us must be made known in writing or by fax within 10 working days after receipt of the invoice. After this period complaints will not be handled anymore.
Complaints will only then be considered if the client has so far complied with all parts of the agreement, regardless of the agreement of which the obligation is resulting.

Description of the device

Features

The DAP PA-530DAB is a compact 30 W, 100 V/8Ω mono mixer amplifier with 5 selectable sources and 2 microphone inputs. Both microphone inputs are equipped with phantom power and can also be selected as line input. The integrated speech filter can be applied to improve audibility. The PA-530DAB has a line input on the rear and an easy accessible Mini-Jack input on the front for connecting MP3 players or mobile devices. It also has a built-in USB audio player and FM/DAB+ tuner with a large LCD screen that displays the active source, tuner information and ID3 tags. The built-in FM/DAB+ tuner can store up to 10 preset stations (5 FM and 5 DAB+). This 100 V mixer amplifier is suitable for small installations up to 30 W. It is designed to support a PA system that is intended for intercommunication or background music in public areas such as convention halls, shopping malls, dining halls, auditoriums and recreational areas. These amplifiers have an integrated protection to protect against overload and short circuit of the output. This results in very high reliability and easy installations without additional audio processors.

Outputs

- Power amplifier RMS output: 30 W
- Output per channel at 70/100 V at 1 kHz: 30 W
- Output channels : 1
- Output mode : Parallel
- Output connector: Terminal
- Headphone output: 1
- Headphone output connector: TRS balanced 6.3 mm

Inputs

- Mono inputs: 2
- Mono input connector: 3-pin XLR, TS unbalanced 6.3 mm
- Stereo inputs: 1
- Stereo input connector: TRS balanced 3.5 mm
- Auxiliary inputs: 1
- Auxiliary input connector: RCA
- Transformer: 100 V

Playback

- Supported audio files: MP3, WAV
- Supported format: FAT16, FAT32
- Maximum storage Size: 64 GB
- Media input/output: USB-A
- Playback functions: Program, Repeat, Continuous , Up (Skip), Down (Skip), Play, Pause, Stop, Time, Folder

Audio Specifications

- Phantom power: 18 V

Sound Editing

- Parametric main equalizer: 2 bands
- Main output equalizer gain range: 12 dB
- Main output fixed frequencies: 100, 12.000 Hz
- Speech filter attenuation: 6 dB
- Speech filter frequency: 300 Hz

Wireless Specifications

- FM frequency start: 87,5 MHz
- FM frequency end: 108 MHz
- FM antenna impedance: 75 Ω
- DAB+ frequency start: 174 MHz
- DAB+ frequency end: 230 MHz

Internal Storage
- User presets: Yes
- User presets capacity: 10 (5 FM and 5 DAB+)

Control and Programming
- Display: 14-segment

Electrical Specifications and Connections
- Power supply: 115-230 V AC 50/60 Hz
- Backup power supply: 24 V DC
- Power consumption: 69 W
- Fuse: 1 A
- Power connector In: IEC
- Data connector In: USB

Mechanical Specifications
- Height: 95 mm
- Width: 270 mm
- Depth: 262 mm
- Installation depth (excl. connector): 262 mm
- Housing: Steel
- Color: Black
- Finish: Powder coating
- Weight: 6 kg
- IP rating: IP20 (indoor use only)
- Amplifier cooling: Axial fan

Product Properties
- Chime: No
- Electronic protection: Overload, short circuit
- LED indicators: Output level, power

Included Items
- Included cables: IEC cable
- Included accessories: FM/DAB+ antenna, green terminal connector, rubber feet

Frontside




Fig. 01

① **Power switch ON/OFF**
Press the button to switch the device ON/OFF.

② **Tuner/audio player**
See section Tuner on page 10, see section Audio Player on page 11 and section DAB+ on page 14.

③ **Master control**
Turn the control to adjust the master volume level, according to your preference.

④ **VU meter**
The clip LED indicates peak levels at the output of the amplifier. If the red LED frequently blinks or lights continuously, the output is likely to enter clipping. If this happens, we strongly suggest turning the **master control (03)** to the left, to decrease the master volume.

⑤ **Headphones 6,3 mm jack OUT**
Use this connector to connect 6,3 mm jack headphones.

⑥ **Source selector**
Turn the control to set the desired signal source or the built-in audio player/tuner. The available sources are:

- 1. FM Tuner
- 2. USB Front
- 3. Aux (in combination with AUX RCA In (**23**))
- 4. Jack 3.5 Front IN
- 5. DAB+ Tuner

⑦ **Volume control**
Turn the control to adjust the volume level of the selected source.

⑧ **Mic 1 level control**
Turn the control to adjust the volume level for input Mic 1.

⑨ **Mic 2 level control**
Turn the control to adjust the volume level for input Mic 2.

⑩ **Bass control**
Turn the control to adjust the bass level of Mic inputs 1-2.

⑪ **Treble control**
Turn the control to adjust the treble level of Mic inputs 1-2.

⑫ **Line/phone switch**
Press the button to switch between level input or phone level input. The phone level adjusts the input sensitivity into the correct level for MP3 players, smartphones or tablets. Now you can playback your MP3 devices directly without signal loss. If phone switch is active the switch lights up orange.

⑬ **Front IN**
Unbalanced stereo 3,5 mm mini jack aux input for connecting a line/phones level device.
Press the **line/phone (12)** switch to set up this input for connecting either phone or line level output devices.

Backside




Fig. 02

⑭ **Air inlet**
Do not obstruct the air inlet.

⑮ **IEC power connector 115–230 V AC 50/60 Hz + fuse T1AL/250V**
Connect the device to the appropriate power supply.

⑯ **AC selector**
Before connecting your PA-530DAB to the mains, make sure that the AC selector is set to the proper voltage which is used in your country. In case of doubt, consult a technician.

⑰ **Mic 2 function DIP switches**
Moving the DIP switches to ON/OFF, allows you to set up combo input 2. The available options are:

- Low-cut (Speech/Filter)
- Phantom
- Line/Mic

Low-cut (Speech/Filter): If set to ON, the device will cut off the lower frequencies of the input signal, which will improve speech audibility. If set to OFF, the low frequencies will not be cut off.

Phantom power: If set to ON, the device will provide power to condenser microphones.

Line/Mic: If set to ON, the input sensitivity will be set for line inputs. If set to OFF, the input sensitivity will be set for microphone level.

⑱ **Gain level control – Mic 2**
Adjust input level for Mic 2.

⑲ **Combo input – Mic 2**
Combo input for Mic 2. Accepts balanced or unbalanced inputs.

⑳ **Mic 1 function DIP switches**
Moving the DIP switches to ON/OFF, allows you to set up combo input 1. The available options are:
- Low-cut (Speech/Filter)
- Phantom
- Line/Mic

Low-cut (Speech/Filter): If set to ON, the device will cut off the lower frequencies of the input signal, which will improve speech audibility. If set to OFF, the low frequencies will not be cut off.

Phantom power: If set to ON, the device will provide power to condenser microphones.

Line/Mic: If set to ON, the input sensitivity will be set for line inputs. If set to OFF, the input sensitivity will be set for microphone level.

㉑ **Gain level control – Mic 1**
Adjust input level for Mic 1.

㉒ **Combo input – Mic 1**
Combo input for Mic 1. Accepts balanced or unbalanced inputs.

㉓ **Aux – RCA IN**
Connect an auxiliary signal source. The **source selector (06)** must be set to **3**.

㉔ **100V/8Ω terminal connector**
If you connect a 100V speaker, connect the main feed cable (+) to the 100V terminal and the common cable (-) to the 0 terminal.
If you connect a low impedance speaker, then connect the main feed cable (+) to the 8Ω terminal and the common cable (-) to the 0 terminal.

NOTE: Do not connect the 100V and 8Ω speakers at the same time.

㉕ **24V DC IN terminal connector**
This input can be used in mobile applications, such as boats where 115 or 230V AC is not available or in applications that must continue to operate in case of power shortage. When a 24V DC battery is connected, the unit will operate on the supplied DC voltage. The amplifier has a built-in charger, which charges the connected battery (lead acid battery only). Make sure, the amplifier is connected to 115 V AC or 230 V AC to enable charging.

㉖ **75 Ω FM antenna connector**
Connect your FM/DAB+ antenna to this connector.

Tuner




Fig. 03

27 **LCD display**
In Tuner mode, the display shows the frequency and the current preset number.
In Audio Player mode, the display shows the current track's name and number, playback time and the current playback mode.

28 **UP button**
Press this button to select the desired station.

29 **DOWN button**
Press this button to select the desired station.

30 **Preset 1 button**
Press this button to recall preset 1.

31 **Preset 2 button**
Press this button to recall preset 2.

32 **Preset 3 button**
Press this button to recall preset 3.

33 **Preset 4 button**
Press this button to recall preset 4.

34 **Preset 5 button**
Press this button to recall preset 5.

Audio Player




Fig. 04

(35) **Repeat button**
Press this button to choose the desired playback modes.

(36) **Time button**
Press this button to toggle between the following 2 time display modes: elapsed time and remaining time.

(37) **Folder button**
Press this button to browse through the directories on your USB flash drive.

(38) **I◄◄ button**
Press the button to skip backwards.

(39) **►►I button**
Press the button to skip forwards.

(40) **■ button**
Press this button to stop playback.

(41) **► II button**
Press this button to start playback. Press this button again to pause playback.

(42) **USB connector A**
Use this connector to connect a USB flash drive with MP3 or WAV files

Installation

Remove all packing materials from the PA-530DAB. Check if all foam and plastic padding is removed. Secure the equipment into a 19" rack if preferred. Connect all cables.

Always disconnect from electric mains power supply before cleaning or servicing.
Damages caused by non-observance are not subject to warranty.

Set Up and Operation

Before plugging the unit in, always make sure that the power supply matches the product specification voltage. Do not attempt to operate a 115V specification product on 230V power, or vice versa.

Before powering up the first time, make sure that the AC selector is set to the proper voltage!

Damage caused by connecting the amplifier to improper AC voltage is not covered by any warranty!


⚠ **Always turn off and disconnect the amplifier from mains voltage before making audio connections. The attenuators should always be turned down during power-up.** ⚠

Connecting Inputs

Use the jack input on the front panel or the RCA/XLR input connectors on the rear to supply audio signals to your DAP Audio PA-530DAB amplifier. The jack connector accepts unbalanced audio connections while the XLR connectors accept balanced and unbalanced audio connections.

Operating the FM Tuner

01) Turn the **source selector (06)** to **1**. The display will show:



Searching for Radio Stations

01) Press the **UP/DOWN buttons (28/29)** to select previous/next radio station. There are 5 available radio presets.
02) You can also press the **preset buttons 1-5 (30/31/32/33/34)** to select one of the first 5 radio stations.

Tuning

01) Press and hold down the ⏮ or ⏭ **buttons (38/39)** for 2 seconds to start automatic tuning. The tuner will keep searching for a strong wavelength. Once it is found, the search will stop.
02) In order to fine-tune the signal quality, press the skip buttons ⏮ and ⏭ to move backwards or forwards, until the quality of the signal is good.

Storing a Radio Station in Memory
If you want to save a newly found radio station as one of the first 5 presets, press and hold down one of the **preset buttons 1-5 (30/31/32/33/34)**. Release the button as soon as the desired preset number appears on the display.

Example: You want to save a newly found radio station on preset 4.
01) Press and hold down the **preset button 4 (33)**.
02) Release the button as soon as the preset number **04** appears on the display.

Operating the DAB+ Tuner

Turn the **source selector (06)** to **5**. The display will show:




Refreshing the DAB+ Radio Station List
01) Press the **Folder button (37)**, the device starts the autoscan. The display shows the progress of the scan and the available stations.
02) Once the scan is completed, you can browse through the station list. This list is not stored. Press the **UP/DOWN buttons (28/29)** to select previous/next radio station. There are 5 available radio presets.

Storing a Radio Station in Memory
If you want to save a newly found radio station as one of the first 5 presets, press and hold down one of the **preset buttons 1-5 (30/31/32/33/34)**. Release the button as soon as the desired preset number appears on the display.

Example: You want to save a newly found radio station on preset 4.
01) Press and hold down the **preset button 4 (33)**.
02) Release the button as soon as the preset number **04** appears on the display.
03) Press the skip buttons ⏮ and ⏭ to select the previous/next stored preset.

Operating the Audio Player

01) Connect the desired music source to the amplifier.
02) Turn the **source selector (06)** to choose the appropriate music source (see Source selector, page 6).
03) The display will show:



Selecting Tracks

01) Press the skip buttons ⏮ and ⏭ to select previous/next track. The selected track's name and time data will appear on the display.
02) Press and hold down the skip buttons ⏮ and ⏭ to rewind/fast-forward the selected track.

Auto Start/Pausing Playback

01) Once you have selected the desired track, playback starts automatically.
02) Press the ⏯ button to pause playback.

Stopping Playback


Press the ⏹ button to stop playback.

Repeat Function

01) Press repeatedly the **Repeat button (35)** to toggle between the following playback modes:
    - **A** – Once the final track from a given folder has passed, the player will skip to the following folder, starting playback from the first track on the list.
    - **F** – Once the final track from the selected folder has passed, the audio player will replay the whole folder, starting from the first track on the list.
    - **S** – Single track mode. The player will repeat the selected track. Each press of the skip buttons ⏮ and ⏭ will cause the player to return to the beginning of the selected track.
02) When the display shows no playback mode indication, once the final track from the selected folder has passed, the player will stop playback.

Selecting Folders and Tracks

01) While playback is active, press the **Folder button (37)**. The display will show:



02) Press the ⏮ and ⏭ buttons to select the desired folder.
03) Press the ⏯ button to enter the selected folder/track. The display will show:



04) Press the ⏮ and ⏭ buttons to select the desired folder/track within the folder.
05) Press the ⏯ button to play/enter the desired track/subfolder.

Connecting Outputs

Speakers are connected by means of terminal connectors. See the examples below.

Low Impedance Outputs

You can use as many speakers as you want as long as the total impedance matches the amplifiers output.

Example 1: Using the 8Ω output with an 8Ω speaker.




Fig. 05

Example 2: Using the 8Ω output with two 4Ω speakers.




Fig. 06

⚠ **In a low impedance system, the total speaker load should always match the amplifier's impedance, in order not to overload the amplifier. The total speaker power should be at least equal to the power of the amplifier, to avoid speaker damage.** ⚠

High Impedance Outputs

While using either the 70V outputs or the 100V outputs, note that all speakers **should be wired in parallel**.

⚠ **The total power of all speakers summed together should never exceed the total power of the amplifier in a 70V or a 100V system!** ⚠

Example 3: 70 V or 100 V setup





Fig. 07


Connection Cables

Take care of your cables, always holding them by the connectors and avoiding knots and twists when coiling them: This gives the advantage of increasing their life and reliability. Periodically check your cables. A great number of problems (faulty contacts, ground hum, discharges, etc.) are caused entirely by using unsuitable or faulty cables.


Unbalanced



Balanced



For these applications the unit provides 1/4" TRS and XLR connectors to easily interface with most professional audio devices. Follow the configuration examples below for your particular connection.



Maintenance

The DAP Audio PA-530DAB requires almost no maintenance. However, you should keep the unit clean. Disconnect the mains power supply, and then wipe the cover with a damp cloth. Do not immerse in liquid. Do not use alcohol or solvents.
Keep connections clean. Disconnect electric power, and then wipe the audio connections with a damp cloth. Make sure connections are thoroughly dry before linking equipment or supplying electric power.

Replacing the Fuse

Power surges, short-circuit or inappropriate electrical power supply may cause a fuse to burn out. If the fuse burns out, the product will not function whatsoever. If this happens, follow the directions below.

01) Unplug the unit from electric power source.
02) Insert a screwdriver into the slot in the fuse cover. Gently pry up the fuse cover. The fuse will come out.
03) Remove the used fuse. If brown or unclear, it is burned out.
04) Insert the replacement fuse into the holder where the old fuse was. Reinsert the fuse cover. Be sure to use a fuse of the same type and specification. See the product specification label for details.

Troubleshooting

DAP Audio PA-530DAB
This troubleshooting guide is meant to help solve simple problems. If a problem occurs, carry out the steps below in sequence until a solution is found. Once the unit operates properly, do not carry out following steps.

01) If the device does not operate properly, unplug the device.
02) Check power from the wall, all cables, connections, etc.
03) Replace the fuse. See page 17 for replacing the fuse.
04) If all of the above appears to be O.K., plug the unit in again.
05) If nothing happens after 30 seconds, unplug the device.
06) Return the device to your DAP Audio dealer.

Product Specifications

Outputs
- Power amplifier RMS output: 30 W
- Output per channel at 70/100 V at 1 kHz: 30 W
- Output channels : 1
- Output mode : Parallel
- Output connector: Terminal
- Headphone output: 1
- Headphone output connector: TRS balanced 6.3 mm

Inputs
- Mono inputs: 2
- Mono input connector: 3-pin XLR, TS unbalanced 6.3 mm
- Stereo inputs: 1
- Stereo input connector: TRS balanced 3.5 mm
- Auxiliary inputs: 1
- Auxiliary input connector: RCA
- Transformer: 100 V

Playback
- Supported audio files: MP3, WAV
- Supported format: FAT16, FAT32
- Maximum storage Size: 64 GB
- Media input/output: USB-A
- Playback functions: Program, Repeat, Continuous , Up (Skip), Down (Skip), Play, Pause, Stop, Time, Folder

Audio Specifications
- Phantom power: 18 V

Sound Editing
- Parametric main equalizer: 2 bands
- Main output equalizer gain range: 12 dB
- Main output fixed frequencies: 100, 12.000 Hz
- Speech filter attenuation: 6 dB
- Speech filter frequency: 300 Hz

Wireless Specifications
- FM frequency start: 87,5 MHz
- FM frequency end: 108 MHz
- FM antenna impedance: 75 Ω
- DAB+ frequency start: 174 MHz
- DAB+ frequency end: 230 MHz

Internal Storage
- User presets: Yes
- User presets capacity: 10 (5 FM and 5 DAB+)

Control and Programming
- Display: 14-segment

Electrical Specifications and Connections
- Power supply: 115-230 V AC 50/60 Hz
- Backup power supply: 24 V DC
- Power consumption: 69 W
- Fuse: 1 A
- Power connector In: IEC
- Data connector In: USB

Mechanical Specifications
- Height: 95 mm
- Width: 270 mm
- Depth: 262 mm
- Installation depth (excl. connector): 262 mm
- Housing: Steel
- Color: Black
- Finish: Powder coating
- Weight: 6 kg
- IP rating: IP20 (indoor use only)
- Amplifier cooling: Axial fan

Product Properties
- Chime: No
- Electronic protection: Overload, short circuit
- LED indicators: Output level, power


Included Items
- Included cables: IEC cable
- Included accessories: FM/DAB+ antenna, green terminal connector, rubber feet

Design and product specifications are subject to change without prior notice.

CE

Website: www.Dap-audio.info
Email: service@highlite.nl

Dimensions


262 mm
95 mm
270 mm
DAP
POWER
UP
DOWN
1
2
3
4
5
REPEAT
TIME
FOLDER
PA-530DAB
CLIP
SOURCE
SOURCE VOLUME
MIC 1
MIC 2
BASS
TREBLE
FRONT IN
MASTER VOLUME

DAP

©2025 DAP Audio